



MITEL

COMMUNICATIONS DIRECTOR

**INSTALLATION AND ADMINISTRATION GUIDE
FOR INDUSTRY STANDARD SERVERS (ISS)
RELEASE 6.0 SP2**



NOTICE

The information contained in this document is believed to be accurate in all respects but is not warranted by Mitel Networks™ Corporation (MITEL®). The information is subject to change without notice and should not be construed in any way as a commitment by Mitel or any of its affiliates or subsidiaries. Mitel and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes.

No part of this document can be reproduced or transmitted in any form or by any means - electronic or mechanical - for any purpose without written permission from Mitel Networks Corporation.

Trademarks

Mitel, SX-200, and SUPERSET are trademarks of Mitel Networks Corporation.

Adobe Acrobat Reader is a registered trademark of Adobe Systems Incorporated.

Window and Microsoft are trademarks of Microsoft Corporation.

Other product names mentioned in this document may be trademarks of their respective companies and are hereby acknowledged.

Mitel Communications Director
Installation and Administration Guide for Industry Standard Servers (ISS)
Release 6.0 SP2

®,™ Trademark of Mitel Networks Corporation
© Copyright 2013, Mitel Networks Corporation
All rights reserved

Chapter 1: Introduction

About this Guide	3
What's New in this Release?	3
MCD Release 6.0 SP2	3
MCD Release 6.0 SP1	3
MCD Release 6.0	3
About Mitel Communications Director (MCD) for ISS	4
Linux Operating Systems	4
Mitel Standard Linux	4
Red Hat Enterprise Linux	4
About the Documentation Set	5
Access Product Documentation	5
View or Download a Document	5
Applications Management Center (AMC) Licensing	6
About AMC Licensing	6
Requesting a New AMC Account	7
Accessing your Account	7

Chapter 2: Software Installation

Installation Overview	11
MCD for ISS on Mitel Standard Linux	12
Before you Begin	12
Collect Site Information	13
Install the MCD for ISS Software	13
Launch the MCD System Administration Tool	14
MCD for ISS on Red Hat Enterprise Linux	16
Preconditions	16
Hardware Requirements	16
Software Requirements	16
Collect Site Information	18
Stratus ftServer 2600/4500 Software Installation and Configuration	18
Stratus ftServer 2700 Software Installation and Configuration	22
RHEL Maintenance Commands	26

Chapter 3: Maintenance and Troubleshooting

Hardware Maintenance	31
Software Maintenance	32
MCD for ISS on Mitel Standard Linux	32
Upgrade the MCD for ISS Software	32
Back up the MCD-ISS Database	35
Restore the MCD-ISS Database	36
Disaster Recovery	37
MCD for ISS on Red Hat Enterprise Linux	39
Upgrade the MCD for ISS Software	39
Back up the Call Server Database	39
Restore the Call Server Database	40
Routine Maintenance Procedures	42
Troubleshooting	44
Installation and Upgrade	44



Chapter 1
Introduction

About this Guide

The Mitel Communications Director (MCD) Installation and Administration Guide is intended for Distributors and Resellers who are installing and configuring MCD software on an Industry Standard Server (ISS).

MCD introduces separate brands for the Mitel range of hardware and software-only solutions for the IP communications market. Mitel Communications Director (MCD) is the brand name of the call-processing software that runs on hardware platforms such as the 3300 ICP and industry standard servers. The 3300 ICP name continues as the brand for Mitel hardware platforms that run MCD.

This guide describes the installation, administration, maintenance, and troubleshooting of the MCD for ISS software on the Mitel Standard Linux (MSL) platform, and Red Hat Enterprise Linux (RHEL) on Stratus fault tolerant hardware.

What's New in this Release?

MCD Release 6.0 SP2

MSL 10.0 is supported effective Release 6.0 SP2.

MCD Release 6.0 SP1

- Effective Release 6.0 SP1, MCD for ISS on RHEL can be installed on the Stratus ftServer 2700 hardware server.
- Embedded Voice Mail Application prompts are installed automatically with the MCD-ISS software on RHEL.
- Support for the Stratus fault tolerant hardware platforms to be a Designated License Manager (DLM).

MCD Release 6.0

- Integrated MCD/MSL Backup. During an MSL backup, the MCD is also backed up, and bundled into the MSL backup file.
- The number of addresses is reduced to one for MSL and one for MCD-ISS.
- When upgrading to Release 6.0, the Automatic Local Network Addition in the MSL Local Network Panels is configured according to the RFC 1918.
- Embedded Voice Mail Application prompts are included in MCD-ISS ISO as a blade.
- Secure Shell Settings are disabled when configuring Remote Access in MSL due to security reasons.

About Mitel Communications Director (MCD) for ISS

Mitel Communications Director (MCD) for ISS is an application package installed and delivered on a server offering PBX functionality. MCD for ISS is based on the 3300 ICP software, utilizing only its call control aspects. Essentially, MCD for ISS treats voice as an application independent of any hardware.

MCD for ISS has the following characteristics:

- a call-control only application, with no TDM or analog interfaces
- IP addressing provisioned during Linux installation
- Layer 2 switching and VLAN tagging performed by an external Layer 2 switch
- Media Server functionality such as conferencing, music on hold, and group paging provisioned as a software solution

Linux Operating Systems

The MCD for ISS is available for installation on two variants of the Linux operating system:

- Mitel Standard Linux
- Red Hat Enterprise Linux

Mitel Standard Linux

Mitel Standard Linux (MSL) is 32-bit operating system and server solution that provides a base for a suite of managed services and applications. MSL can be installed on a variety of hardware server platforms and, during installation, provision IP addressing. To protect data integrity, MSL can be configured to support disk mirroring (RAID 1).

When it is installed on MSL, MCD for ISS contains a software application *blade* that offers PBX functionality independent of any specialized hardware.

Red Hat Enterprise Linux

Red Hat Enterprise Linux (RHEL) is a 64-bit operating system targeted toward the commercial market. In the current release, RHEL must be installed on a Stratus® ftServer system. The Stratus system provides the following advantages:

- Redundant CPU, power and network connections.
- Continuous availability of local devices and applications.
- Continuous availability of remote suites hosted on analog controllers.

When it is installed on RHEL, MCD for ISS provides PBX functionality on the Stratus ftServer system.

About the Documentation Set

To access the documentation pages at Mitel OnLine, go to <http://edocs.mitel.com>. You require a Mitel Online username and password to access the documents on this web site.

Mitel Communications Director:

- *Mitel Communications Director Installation and Administration Guide for ISS* (this guide) provides installation, administration, maintenance, and troubleshooting instructions for the MCD software.
- *Mitel Communications Director for 3300 ICP System Administration Tool Help* provides administration and programming procedures for the call control aspects of the product.
- *Engineering Guidelines for Industry Standard Servers (ISS) and Virtual Mitel Communications Director (vMCD)* provides information on hardware and available configurations.

Access Product Documentation

1. Go to www.edocs.mitel.com.
2. Select a documentation suite from one of the following drop-down menus:
 - Communications Platforms
 - Messaging
 - Applications & Solutions
 - Software Development
 - End User Documents
3. Log in if asked to do so.
 **Note:** For Technical Bulletins (TB) and Release Notes (RN), click **Knowledge Base** in the **Other Resources** window in the left-side navigation pane.
4. To access IP Phone documentation, select **PDF Guides** from the **End User Documents** drop-down menu at the top of the page.

View or Download a Document

To view a document:

- Click the document title.

To download a document:

- Right-click on the document title, and then click **Save Target As**.
OR
When viewing a PDF document, click the disk icon.

Applications Management Center (AMC) Licensing

The Mitel Applications Management Center (AMC) is an online service accessed through the web that provides licensing, monitoring, management, and a variety of other services for installations of software applications.

About AMC Licensing

The AMC allows licensing keys to be automatically created at all times (24 hours a day, 7 days a week) through remote license keys generation.

The AMC is also the procurement and provisioning interface for AMC-delivered products and services. As a reseller of Mitel products, you receive a unique licensing account on the AMC. By logging in to the AMC with the username and password you are given when you obtain your account, you can view a list of your AMC-enabled products, check their status, and add services to any of them.

When you place a new order for products with the Mitel Customer Care Center, the order information is entered into the AMC system. The AMC places the purchased licenses into your licensing account for use in creating an application record. You must:

1. Install the MCD application.
2. Log in to the AMC.
3. Create the application record.
4. Assign purchased products, features, and options to that application record.
5. Activate the customer's MSL or RHEL operating system.

MCD for ISS is delivered in a software only format for field installation on industry standard platforms. The software can be obtained in several methods:

- *Download from the AMC (MSL only)* — The MCD blade can be downloaded from the AMC through the regular MSL software blade download mechanism.
- *Download from Mitel OnLineSoftware (MSL or RHEL)* — The MCD ISO image can be downloaded from Mitel OnLine, burned to a CD-ROM or stored on a network drive. The software can then be installed from either location onto the server.

The MCD for ISS application uses the AMC to obtain licensing information, which is required for installing main base software, for installing upgrade software (language packs excluded), and for installing system option upgrade software (language packs excluded). To complete the installation from the AMC, you must install the operating system and register it with the AMC online, and then install and upgrade MCD for ISS and all your purchased options.

When the installation of the MSL or RHEL operating system software is complete, the system generates a unique Hardware ID that includes the MAC address of the server. When you connect to the AMC over the Internet, the system uses the Hardware ID and the Application Record ID to communicate with the AMC to obtain licensing information.

For additional information about the Mitel Applications Management Center (AMC), refer to the AMC Web site and the AMC online Help (<https://www.mitel-amc.com/>).

Requesting a New AMC Account

To request an AMC account, send an e-mail containing the following information to amc_accounts@mitel.com:

- Name of your certified Technician
- Full company name
- Company mailing address
- Phone 1/Phone2
- Fax number
- Admin e-mail (address of the person who should receive notification of service expiry dates)
- Tech e-mail (address of the person who should receive notification of update releases and other technical notices)
- Company URL (if any)
- Your Mitel SAP account number
- Specify if you would like your user ID and password delivered to you by fax, phone, or both (for security reasons user IDs and passwords are not sent by e-mail).



Note: Please allow two business days for your AMC account to be created.

Accessing your Account

To access your account for the first time:

1. Go to the Mitel web site (<http://www.mitel.com>) and log in to your Mitel OnLine account.
2. In the grey menu bar, point to Online Tools and then click AMC.
3. Sign in with your unique AMC ID and password to establish your "single sign on". On subsequent visits, you access your AMC account directly after signing in to Mitel OnLine.

For information about using the AMC, click the online Help link in your AMC account.



Chapter 2

Software Installation

Installation Overview

The MCD for ISS is available for installation on two variants of the Linux operating system. For details, see:

- “MCD for ISS on Mitel Standard Linux” on page 12
- “MCD for ISS on Red Hat Enterprise Linux” on page 16

MCD for ISS on Mitel Standard Linux

The following procedure describes how to install Mitel Communicator (MCD) software on a Mitel Standard Linux (MSL) platform.

Before you Begin

The following conditions must be in place before you begin the installation process:

- An industry standard server platform installed with the MSL operating system. A list of qualified servers is available at www.edocs.mitel.com.

Caution: Ensure that the 32-bit version of MSL is installed as the operating system.

- Internet Explorer, minimum version 8.xx (with the latest Service Pack), can be run on a Windows workstation on the same subnet as the server being installed.
- Internet access to allow licensing from the Applications Management Center (AMC).
- If you are changing the hardware or re-formatting the hard-drive, you must clear the Hardware ID as part of the AMC licensing process.
- Access to the following network resources:
 - Domain Name System (DNS) server
 - Default Gateway
 - Network Time Protocol (NTP) server
- IP addresses available for MSL and the Call Server. Effectively, you need one address for MSL and one address for MCD for ISS on the same subnet as the MSL server. The addresses do not need to be consecutive.

For example, if the host MSL server has the following network configuration:

- MSL IP address: 10.38.193.2/24
- Default Gateway IP address: 10.38.193.1

The available remaining addresses on the subnetwork are 10.38.193.3 to 10.38.193.254. Assign one available IP address to the MCD for ISS blade.

- A monitor and keyboard attached to the server upon which you are installing the software and applications.
- The ISO images downloaded and burned to a CD, or installed from the AMC. Install the software blade using the MSL Server Manager as described in “Install the MCD for ISS Software” on page 13.
- Correct versions of the software and applications.
Go to Mitel Online at <https://www.ebiz.mitel.com>. Point to **Services and Support**, click on **Technical Resources**, then select **Software Downloads**.

Collect Site Information

The following table itemizes the information you will need on hand during installation and configuration. For efficient installation, it is recommended that you gather this information beforehand.

Item	Notes	Your Information
Administrator Password	For password strength, choose a password that contains a mix of upper and lower case letters, numbers, and punctuation characters, and that is not a dictionary word.	
Domain Name of MSLServer	Names must start with a letter; can contain letters, numbers, and hyphens.	
System Name of MSLServer		
IP Address of your external NIC	The IP address of your external Ethernet connection.	
System IP Address for MCD for ISS blade	The IP address for the MCD for ISS system. Note that this address must be in the same subnet as the MSL address.	
Application Record ID	The number generated when you purchase the MCD product from AMC.	

Install the MCD for ISS Software

The MCD for ISS software blade is installed from the blade panel in the MSL Server Manager. Installing and activating the MCD for ISS software blade consists of the following steps:

- Logging in to the MSL Server Manager
- Loading the software onto the MSL Server from the MCD for ISS CD, or download it from the AMC and then accessing the blade panel in the MSL Server Manager to install the MCD for ISS software blade.

To install the MCD-ISS software on MSL:

1. **OPTIONAL:** If installing from a CD, then place the CD in the optical drive.
2. Login into the Server Manager using Internet Explorer with the user name '*admin*' and the password you gave when configuring the MSL server.
The Server Manager is accessed by entering the following URL:
http://<www.hostname> OR <IP address of the MSL Server>/server-manager
3. Click on **Status**, located in the left-side panel under the **ServiceLink** heading.
4. Enter your ARID.
5. Scroll to the bottom of the page and click on **Sync**. The message "Please wait a moment for the sync to complete." It may take a few minutes for the synchronization to complete.

6. Click on **Blades**, located in the left-side panel under the **ServiceLink** heading.
7. Click **Update List** to ensure an up-to-date listing of software blades.
8. Click the **Install** link, located beside the MCD for ISS blade name.
It may take a few minutes for the software to install.
9. Click the **Install** link located beside the *EMEM Prompts* blade name.
It may take a few minutes for the software to install.
10. When the installation is complete, click on **Mitel Communications Director**, located in the left-side panel under the **Applications** heading.
11. On the next screen click **Modify**.
12. Configure the System IP address for the MCD for ISS blade. The IP address should be in the MSL network subnet.



Note: If the MSL IP address falls under one of the RFC 1918 private local networks, the corresponding network is added in Local Networks. For example, if the MSL IP address is 10.45.102.222, then in the Local Networks you will see 10.0.0.0.

1. Click **Local Networks**, located in the left-side panel under the **Security** heading.
 2. In the right-side main window, click **Add Network**.
 3. In the **Network Address** field, enter the IP address of the network to designate as "local".
 4. In the **Subnet Mask** field, enter the mask to apply to the Network Address.
 5. In the **Router** field, enter the IP address of the router you will use to access the newly-added network.
 6. Click **Add**.
13. Click **Save**.
 14. Test the installation:
 - a. log into the MCD for ISS System Administration Tool
 - b. navigate to the **License and Options (LOS)** form
 - c. check that the license information is properly displayed

Launch the MCD System Administration Tool

The MCD System Administration Tool provides a web-based interface that trained technicians use to perform the following functions:

- System Configuration
- System Administration
- Maintenance and Diagnostics
- Accessing programming and configuration forms

To launch the MCD System Administration Tool:

1. Browse to the System IP address for the MCD for ISS blade using Internet Explorer.



Note: This is the IP address you entered in Step 12 of "Install the MCD for ISS Software" above, and gives you access to the MCD Embedded System Manager (ESM).



Note: You will be prompted to choose between using the Telephone Directory synchronization via OPS Manager or via System Data Synchronization (SDS).

2. Enter the username '*system*' and the password '*password*'.



Note: If logging in for the first time, you will be prompted to enter a new password. **Do not forget** this new password!

3. Click on **System Administration Tool**.

For more information about the MCD System Administration Tool, see the *Mitel Communications Director for 3300 ICP System Administration Tool Help*.

MCD for ISS on Red Hat Enterprise Linux

The following procedure describes how to install Mitel Communicator (MCD) software on a Red Hat Enterprise Linux (RHEL) platform.



Note: In the current release MCD for RHEL can be installed only on a Stratus® ftServer hardware server system. For details, see "Hardware Requirements" below.

Preconditions

The following hardware and software requirements must be met before installing MCD for ISS.

Hardware Requirements

You require one of the following Stratus hardware server options:

Server	Description	Install & Configuration Procedure
ftServer 2600	Rack Mountable, 1-way, DMR, one 2.0 GHz quad-core processor	ftServer 2600/4500 - page 18
ftServer 4500	Rack Mountable, 2-way, DMR, two 2.0 GHz quad-core processors	
ftServer 2700	Rack Mountable, 1-way, DMR, one 1.8 GHz quad-core Processor	ftServer 2700 - page 22
<p>Notes:</p> <ol style="list-style-type: none"> 1. Before beginning the software installation process, ensure that the ftServer system contains only one hard drive in each server plane. If the system contains additional hard drives, remove them. 2. Your ftServer must also be equipped with an ASN modem and at least 4 GB of DDR3 RAM. 3. The ftServer 2700 can be installed conjunction with MCD-ISS Release 6.0 SP1 or later software. 		

Software Requirements

You require the following operating system and application media:

Server	Media (CD/DVDs)	Software Version
ftServer 4500	Stratus ftServer System Software	7.0.4.x
- or - ftServer 2600	Red Hat Enterprise Linux (RHEL) operating system and supplementary media	5.4
	MCD for ISS image (includes Embedded Voice Mail application prompts)	MCD-ISS R5.0 or later

Server	Media (CD/DVDs)	Software Version
ftServer 2700	Stratus ftServer Automated Uptime Layer (AUL) media	9.0.3.x
	Red Hat Enterprise Linux (RHEL) operating system and supplementary media + RHEL subscription	6.3
	MCD for ISS image (includes Embedded Voice Mail application prompts)	MCD-ISS R6.0 SP1 or later
Notes: <ol style="list-style-type: none"> 1. Approved versions of the Stratus and RHEL media, provided by Stratus Technologies Inc., is included with your ftServer system. 2. Download the MCD for ISS image from Mitel Online (https://www.ebiz.mitel.com) and then burn the image to a CD. 3. Refer to the product release notes for the latest information concerning the required software versions. 		

- You require Internet access to allow licensing from the Applications Management Center (AMC). As a minimum:
 - Open port 53 if there is no local/corporate DNS server
 - Open port 22 and, if you are operating an ftServer 2700, 2600, or 4500, allow SSH V1
 - To facilitate PING, allow ICMP echo request (type 8) and reply (type 0) packets to traverse the firewall.
- If you are changing the hardware or re-formatting the hard-drive, you will need to clear the Hardware ID as part of the AMC licensing process.
- Internet Explorer, minimum version 6.xx (with the latest Service Pack), must be accessible on a Windows workstation on the same subnet as the server being installed.
- The server must be able to access to the following network resources:
 - Domain Name System (DNS) server
 - Default Gateway
 - Network Time Protocol (NTP) server
- You require a range of IP addresses the implementation. Effectively, you need one address for Linux and four addresses for MCD for ISS. For example, if the host Linux server has the following network configuration:
 - Linux IP address: 10.38.193.2/24
 - Default Gateway IP address: 10.38.193.1

The available remaining addresses on the subnetwork are 10.38.193.3 to 10.38.193.254. Overlay the Linux server's /24 network with a /30 subnetwork containing four addresses. Assign one these addresses to the MCD for ISS blade while reserving the others for use as network and broadcast addresses. The following table illustrates this configuration:

IP Address	Description
10.38.193.0	Network address

IP Address	Description
10.38.193.1	Default Gateway (router) address
10.38.193.2	Linux server IP address
10.38.193.3	Spare
10.38.193.4	MCD subnetwork address
10.38.193.5	MCD system IP address
10.38.193.6	Reserved
10.38.193.7	MCD subnetwork broadcast address

- You require a monitor and keyboard attached to the Stratus server.

Collect Site Information

The following table itemizes the information you will need on hand during installation and configuration. For efficient installation, it is recommended that you gather this information beforehand.

Item	Notes	Your Information
Administrator Password	For password strength, choose a password that contains a mix of upper and lower case letters, numbers, and punctuation characters, and that is not a dictionary word.	
Linux Network information	<ul style="list-style-type: none"> • Linux domain • Linux server IP address • Default Gateway and subnet mask 	
MCD for ISS blade system IP Address	The IP address for the MCD for ISS system, which falls within a /30 subnetwork.	
Network Time Protocol server address	The IP address or FQDN of the NTP server.	
Application Record ID	The number generated when you purchase the MCD product from AMC.	

Stratus ftServer 2600/4500 Software Installation and Configuration

Employ the following procedures to install MCD for ISS on either of the following Stratus hardware server platforms:

- ftServer 4500 Rack Mountable, 2-way, DMR, two 2.0 GHz quad-core processors
- ftServer 2600 Rack Mountable, 1-way, DMR, one 2.0 GHz quad-core processor

**Notes:**

1. The following procedure outlines the *basic* steps to install RHEL software and configure the Stratus ftServer platform. For more detailed instructions, please refer to the Stratus and Red Hat product documentation.
2. Before beginning the software installation process, ensure that the ftServer system contains only one hard drive in each server plane. If the system contains additional hard drives, remove them.

Configure the ftServer System for Installation

1. Insert the Stratus ftServer System Software media into the server's CD/DVD ROM drive.
2. Turn on the server, or if the server is already running, restart it by entering:
shutdown -r now
3. During the boot sequence, press F2 to enter the BIOS setup.
4. In the BIOS, make the following configuration changes:
 - a. Disable **OS Boot Monitoring**
(located under Server > Monitoring Configuration)
 - b. Disable **Option ROM** for **Embedded PXE#1** and **Embedded PXE#2**
(located under Advanced > Option ROM Configuration)
 - c. Enable **Embedded SAS option ROM**
(located under Advanced > Option ROM Configuration)
 - d. Set the CD/DVD ROM drive as the first boot device.
 - e. Press F10 to save and exit.
5. To set up the server for a minimal RHEL installation, access the boot prompt and enter:
ftSys_min
6. Click **Tab**.
7. When the Stratus error message appears, click **OK** to clear it.
8. Select **Installation Method - Local CDRom**.
9. Click **Tab**, and then click **OK**.
10. Remove the Stratus ftServer System Software media.

Install the Red Hat Enterprise Linux Operating System

1. Insert the Red Hat Enterprise Linux media, and then click **OK**.
2. After the OS installation is complete, remove the Red Hat Enterprise Linux media and press <ENTER> to reboot the system.

Wait for the server to reboot.

3. At the Setup Agent screen, select **Network Configuration** and make the following changes to the DNS configuration:

- a. **Hostname** <FQDN>.
e.g. mcd-rhel.company.com
- b. **Primary DNS** <IP address>.
- c. **Secondary DNS** <IP address> (optional).

Click **Save & Quit**, and then **Exit**.



Note: If the DNS prompts fail to appear, log in as shown in the next step, and then type **setup**.

4. At the Stratus login prompt, enter:

root (login)

ftServer (password)

Install the Red Hat Enterprise Supplementary Packages

1. Insert the Red Hat Enterprise Linux Supplementary media.
2. To mount the media, enter:
mount /dev/cdrom /media
3. To change directories, enter:
cd /media/Supplementary
4. To install Java, enter:
rpm -Uhv java-*sun-1*x86*
5. To change directories, enter:
cd /
6. To unmount the media, enter:
umount /media
7. To eject the media, enter:
eject /dev/cdrom
8. Remove the Red Hat Enterprise Linux Supplementary media.

Install the ftServer System Software

1. Insert the Stratus ftServer System Software media.
2. To mount the media, enter:
mount /dev/cdrom /media
3. To install the Stratus drivers, enter:
/media/install.sh --yes --eulas --reboot
4. During the boot sequence, press F2 to enter the BIOS setup.

5. In the BIOS, make the following configuration changes:

Enable **OS Boot Monitoring** (located under Server > Monitoring Configuration).

6. Exit the BIOS to complete the boot process.
7. Optionally, change the root password by logging in and entering the following command:

passwd

8. Remove the Stratus ftServer System Software media.
9. Connect Ethernet cable(s) to the NIC.



Note: RHEL and the system drivers have been installed, but the Ethernet interfaces are not yet functional. To complete the setup, do the next procedure.

Install the MCD for ISS Software



Note: The MCD for ISS software includes Embedded Voice Mail application prompts, which are installed automatically. Before using the Embedded Voice Mail feature, you must purchase and install voice mail licenses.

1. Insert the MCD for ISS image media.
2. Open a command prompt.
3. To mount the MCD-ISS image, enter:

mount /dev/cdrom /media

4. To run the installation script, enter:

/media/Software/RHEL/install.sh

5. To configure the MCD-ISS network information (Domain name of server, Linux server, Default Gateway and Subnet Mask), enter:

mcd_setup network <Domain-of-Server-FQDN> <Linux-Server-IP> <Default-GW-IP> <Subnet-Mask>

6. To configure the MCD-ISS Network Time Protocol (NTP) information, enter:

mcd_setup ntp <NTP-Server FQDN or IP address>

7. To configure the MCD-ISS Application Record ID (ARID) license information, enter:

mcd_setup ARID <ARID-ID>

8. To configure the call MCD call control server and complete the configuration, enter:

mcd_setup MCD <Call-Control-Server-IP>

9. Complete the MCD call server configuration via the MCD System Administration tool.

Stratus ftServer 2700 Software Installation and Configuration

Employ the following procedures to install MCD for ISS on the Stratus ftServer 2700 hardware server.



Notes:

1. The following procedure outlines the *basic* steps to install RHEL software and configure the Stratus ftServer platform. For more detailed instructions, please refer to the Stratus and Red Hat product documentation.
2. As part of the installation process, you are required to upgrade the RHEL kernel. To obtain the correct upgrade command for your implementation, please refer to the *MCD for ISS Release Notes*. (See page 24 for details regarding the command.)
3. Before beginning the software installation process, ensure that the ftServer system contains only one hard drive in each server plane. If the system contains additional hard drives, remove them.
4. Ensure that only one ethernet port is connected to the network. Connect port 1 on each server plane.

Configure the Stratus ftServer System for Installation

1. Insert the Stratus ftServer AUL media into the server's CD/DVD ROM drive.
2. Turn on the server, or if the server is already running, restart it by entering:
shutdown -r now
3. During the boot sequence, press **F2** to enter the BIOS setup.
4. In the BIOS, make the following configuration changes:
 - a. In **Server**
 - Disable all **Option ROM Scan Monitoring**
 - Disable **OS Boot Monitoring**
 - b. In **Advanced > PCI Configuration**
 - Enable **Embedded SAS option ROM**
 - Disable all other options
 - Press **ESC** to return
 - c. In **Boot > Boot Option #1:**
 - Set the CD/DVD ROM drive as the first boot device. Select the device that contains "DVD-RAM".
 - d. Press **F4** to save and exit.
5. In the Automated Uptime Layer welcome screen select:
Install the system with minimal Uptime Assurance defaults, and then press **Enter**.
This sets up the server for a minimal RHEL installation.
6. Wait for the **Installation Method** screen to appear, prompting you to specify the location of the boot media.

7. Remove the Stratus ftServer Automated Uptime Layer media.

Install the Red Hat Enterprise Linux Operating System

1. Insert the Red Hat Enterprise Linux media.
2. Select **Installation Method - Local CD/DVD**.
3. Click **Tab**, and then click **OK**.
4. After the OS installation is complete, remove the Red Hat Enterprise Linux media and press <ENTER> to reboot the system.

Wait for the server to reboot.

5. At the Stratus login prompt, enter:

root (login)

ftServer (password)

Install the Red Hat Enterprise Linux Supplementary Packages

1. Insert the Red Hat Enterprise Linux Supplementary media.
2. To mount the media, enter:
mount /dev/cdrom /media
3. To change directories, enter:
cd /media/Packages
4. To install Java, enter:
rpm -Uhv java-*sun-1*x86*
5. To change directories, enter:
cd /
6. To unmount the media, enter:
umount /media
7. To eject the media, enter:
eject /dev/cdrom
8. Remove the Red Hat Enterprise Linux Supplementary media.

Configure the Network Settings, Register with Red Hat Network (RHN) and Upgrade the Kernel

1. Connect Ethernet cable(s) to the NIC.
2. Type **setup** to access the Network configuration and update the following:
 - a. DNS configuration:
 - **Hostname** <FQDN>.
e.g. mcd-rhel.company.com
 - **Primary DNS** <IP Address>.

- **Secondary DNS** (optional).
 - Click **OK**
 - b. Device configuration (to configure Linux host IP address):
 - Select **eth0**
 - Deselect **Use DHCP**
 - Program the **Static IP, Netmask** and **Default gateway IP**
 - Click **OK**
 - Click **Save**
 - c. Click **Save & Quit**
 - d. Click **Quit**
3. At the command prompt, enable eth0 device:

```
ifup eth0
```

4. Register your system with Red Hat Network:
- a. Type **setup** to access the RHN Register.
 - b. In RHN Register, click **Next** to proceed.
 - c. Enter your RHN login/password and click **Next**.
 - d. Follow the instructions, and then click **Finish** when prompted.
 - e. Click **Quit**
5. To upgrade the RHEL kernel, enter:

```
yum install kernel-2.6.32-279.19.1.el6 kernel-devel-2.6.32-279.19.1.el6  
kernel-firmware-2.6.32-279.19.1.el6
```



Note: The above-noted command is an example only. To obtain the correct command for your implementation, refer to the product release notes. Entering an invalid RHEL upgrade command may cause your implementation to fail.

Install ftServer Automated Uptime Layer Software

1. Insert the Stratus ftServer AUL media.
2. To mount the media, enter:

```
mount /dev/cdrom /media
```
3. To install the Stratus drivers, enter:

```
/media/install.sh --yes --eulas --reboot
```
4. During the boot sequence, press **F2** to enter the BIOS setup.
5. In the BIOS, make the following configuration changes:
Enable **OS Boot Monitoring** (located under Server).
6. Exit the BIOS to complete the boot process.

7. Respond to the prompt asking you to approve of system health information being sent to Stratus over the Internet.
8. Optionally, change the root password by entering the following command:

```
passwd
```

9. Remove the Stratus ftServer AUL media.

Install MCD for ISS Software



Note: The MCD for ISS software includes Embedded Voice Mail application prompts, which are installed automatically. Before using the Embedded Voice Mail feature, you must purchase and install voice mail licenses.

1. Insert the MCD-ISS image media.
2. To mount the MCD-ISS image, enter:

```
mount /dev/cdrom /media
```

3. To run the installation script, enter:

```
/media/Software/RHEL/install.sh
```

4. Remove the MCD-ISS media.



Note: After the software is installed, the system *may* reboot automatically. Wait for this process to finish before performing the next step (disabling the 2nd bond interface).

5. To ensure the second bond interface is disabled, enter:

```
ifdown bond1
```

Configure the MCD for ISS Software

1. To configure the MCD-ISS network information (Domain name of server, RHEL server, Default Gateway and Subnet Mask), enter:

```
mcd_setup network <Domain-of-Server-FQDN> <RHEL-Server-IP> <Default-GW-IP>  
<Subnet-Mask>
```

2. To configure the MCD-ISS Network Time Protocol (NTP) information, enter:

```
mcd_setup ntp <NTP-Server FQDN or IP address>
```

3. To configure the MCD call control server, enter:

```
mcd_setup MCD <Call-Control-Server-IP>
```

4. To configure the MCD-ISS Application Record ID (ARID) license information, enter:

```
mcd_setup ARID <ARID-ID>
```

5. The MCD call server will reboot for the license information to take effect.
6. Complete the MCD call server configuration via the MCD System Administration tool.

RHEL Maintenance Commands

Following installation, you can use the following commands to maintain and troubleshoot the server.

MCD_SETUP

Use this command to configure the system’s network information, ARID and and NTP settings.

Options	Description	Syntax
network	To enter the RHEL server domain, default gateway, and subnet mask.	<code>mcd_setup network <server-domain-FQDN> <default-GW-IP> <subnet-mask></code>
ARID	To clear the current application record ID (ARID) on the RHEL server.	<code>mcd_setup arid clear</code>
	To enter a new ARID (after clearing the current ARID)	<code>mcd_setup arid nnnnn</code>
	To synchronize with the AMC (typically performed after purchasing new options).	<code>mcd_setup arid sync</code>
ntp	To enter the Network Time Protocol (NTP) server address on the RHEL server.	<code>mcd_setup ntp <NTP-server IP or FQDN></code>
MCD	To enter the MCD IP address (if this is changed while the MCD is running, the system is automatically rebooted).	<code>mcd_setup mcd <IP></code>
	To clear the MCD’s IP address (if this is entered while the MCD is running, the change will take effect the next time the system is rebooted, causing the MCD to be unable to restart)	<code>mcd_setup mcd clear</code>
	To invoke an online upgrade after installing a new MCD software load.	<code>mcd_setup upgrade</code>

MCD_STATUS

Use this command to do the following:

- monitor the system upgrade or licensing status
- verify that the MCD is licensed
- display the current logging operation (license/upgrade) to the screen using the -v modifier (for example, `mcd_status -v`)

MCD_LOGS_COLLECT

Use this command to collect a set of system logs. The resulting tarball file is located under /tmp/mcd-logs.tgz.



Chapter 3

Maintenance and Troubleshooting

Hardware Maintenance

Because MCD for ISS is hardware-independent, the following maintenance commands are not required and not described:

- Show Stratus Redundant
- L2 maintenance commands
- DSP maintenance commands
- SWAP

Hardware maintenance is now specific to the servers and associated components upon which the software has been installed. Please refer to those manufacturer's documentation for hardware maintenance.

Software Maintenance

Software maintenance involves upgrading the MCD for ISS blade, backing up and restoring the databases, and performing basic maintenance commands.

For details, see:

- “MCD for ISS on Mitel Standard Linux” on page 32
- “MCD for ISS on Red Hat Enterprise Linux” on page 39

Caution: During the upgrade process, the MCD application may need to be restarted which will result in service degradation.

MCD for ISS on Mitel Standard Linux

Upgrade the MCD for ISS Software

Different upgrade paths are available and depending on the path, specific procedures need to be carried out. The table below shows which procedure to use for each upgrade path.

Upgrade path	Use this procedure
MCD 6.0 → MCD 6.0 SP1	“Upgrade the MCD for ISS software blade using the online upgrade utility” on page 32
MCD 6.0 → MCD 6.0 SP2	“Upgrade the MCD for ISS software using a fresh installation” on page 33
MCD 6.0 SP1 → MCD 6.0 SP2	“Upgrade the MCD for ISS software using a fresh installation” on page 33



Note: Ensure that there is an internet connection to allow for AMC access.

Upgrade the MCD for ISS software blade using the online upgrade utility

This procedure takes into account that the MSL operating system does not need to be upgraded. Backing up and restoring the databases are part of the online upgrade process.

Caution: This upgrade process will cause a service interruption.

1. **OPTIONAL:** If installing the MCD-ISS software from a CD, then place the CD in the optical drive.

2. Log in to the MSL Server Manager using a browser with the user name and password when initially configuring the MSL server.
3. Click on **Blades**, located in the left-side panel under the **ServiceLink** heading.
4. Click **Update List** to view the new versions available from the AMC in the blade list.
5. In the MCD for ISS row of the list of blades, click on the **Upgrade** link beside the version being upgraded. The End User License page appears.
6. Scroll to the bottom of the page and click **Accept all licenses**. A page showing the upgrade progress appears.
7. When the installation is complete, click **Clear this report**.



Time: The installation time is dependent on the size of the database being backed up. The system takes approximately 30 to 90 minutes to back up an average-sized database (50 - 100 MB).

8. Click **Mitel Communications Director**, located in the left-side panel under the **Applications** heading. A message appears describing the status of the upgrade.

Upgrade the MCD for ISS software using a fresh installation

The fresh installation process involves "flattening the server" and consists of the following steps:

- Backing up the MSL and MCD-ISS databases
- Installing the new version the MSL operating system
- Re-installing a new version of the MCD-ISS software
- Restoring the databases

Database information such as the System (Call Server) IP, local network settings, date and time settings, ARID, etc. is retained in the databases during the upgrade process.

Caution: This procedure will cause a service interruption.



Note: This procedure also backs up all application data through the MSL backup feature. Performing a separate backup of the MCD-ISS database (below) may not be necessary, depending on local administration/maintenance protocols.

1. Backup MSL and the MCD-ISS databases:
 - a. Log in to the MSL Server Manager using a browser with the user name and password when initially configuring the MSL server.
 - b. Click on **Backup**, located in the left-side panel under the **Administration** heading.
 - c. In the **Select an action** drop-down list, choose to back up to either a desktop or network location.
 - d. Click **Perform**.

2. **Optional:** Backup the MCD-ISS database on an external PC using the MCD ESM backup facility (see “Back up the MCD-ISS Database” on page 35).
3. Obtain a printout or an export copy of the licence and options form to determine which configuration options need to be set after installing the new blade.
4. Install the new MSL operating system software. See the *Mitel Standard Linux Installation and Administration Guide* for details.



Note: During installation, make sure to select the following options:

- Erase all disks and perform fresh install
- Yes, when prompted to restore from backup



Note: Physical servers running MSL 9.3 or 9.4 can upgrade to MSL 10 without the need for physical media or console access, by using the Remote Fresh Install (RFI) blade feature. The RFI blade requires sufficient disk space for a backup. If the system has insufficient disk space, the blade will not be listed on the Blades panel. See the *Mitel Standard Linux Installation and Administration Guide* for details.

Once the server has been re-configured, log back into the MSL Server Manager with the user name and password when configuring the upgraded MSL server.

5. **Optional:** If installing the MCD-ISS software from a CD, then place the CD in the optical drive.
6. Click on **Status**, located in the left-side panel under the **ServiceLink** heading.
7. Enter your ARID.
8. Scroll to the bottom of the page and click on **Sync**. The message "Please wait a moment for the sync to complete." It may take a few minutes for the synchronization to complete.
9. Click on **Blades**, located in the left-side panel under the **ServiceLink** heading.
10. Click **Update List** to view the new version available from the AMC in the blade list.
11. Click the **Install** link, located beside the MCD for ISS blade name to start the installation process. The End User License page appears.
12. Scroll to the bottom of the page and click **Accept all licenses**. A page showing the installation progress appears.



Time: The installation process may take up to 5 minutes to complete.

13. Click the **Install** link located beside the *EMEM Prompts* blade name. It may take a few minutes for the software to install.
14. Click **Mitel Communications Director**, located in the left-side panel under the **Applications** heading. Wait until the MCD has been licensed. When the MCD is licensed, the status field in the MCD-ISS web page is changed to *Licensed*.
15. Click **Restore MCD Backup File**.

16. Click **Browse** opposite the **MCD or MSL Backup File Path** field, and navigate to the location of the backup file.
Click **Upload**.



Note: This will restore the MCD-ISS databases. If for some reason the database is not restored, use the “Restore the MCD-ISS Database” procedure on page 36.



Note: You will need to select **Use dimensions from backup file** in the restore window.

Refer to the product Release Notes for any additional information.

Back up the MCD-ISS Database



Tip: It is very important to maintain current database backups; backups should be done on a regular basis.



Note: A MCD-ISS Database backup is only needed if you are upgrading from a version prior to Release 6.0, or when upgrading to Release 6.0 SP2. Otherwise only an MSL backup is needed for MCD-ISS Release 6.0 SP1 or earlier.

You need the following information and equipment to back up a database:

- Installer PC
- System IP address
- System Administration Tool username and password

Use the following procedure to back up a database.



Time: The system takes approximately 10 to 15 minutes to back up an average-sized database (50 - 100 MB).

Caution: During a system backup, no other users can access any of the web- based tools (Desktop Tool, Group Administration Tool, or System Administration Tool), or save changes. To avoid blocking other users, we recommended that you perform system backups outside of business hours.

1. Access the MCD System Administration Tool. See “Launch the MCD System Administration Tool” on page 14.
2. Click **Maintenance and Diagnostics** from the drop-down menu in the **Selection** area on the left.
3. Click **Backup**.
4. Copy the **identitydb.obj** file to your PC (required for every user profile on every PC used for backup and restore). Follow the instructions displayed on the screen.



Tip: Do this only once per PC per user.

5. Click **Browse** to launch the **Save As** dialog box, then navigate to the location on your local drive where you want to save the backup file (for example C:\3300_ICP\backup).
6. Type a name for your backup file, and then click **Save As**.
7. Select the check box for Call History records if you want them included in your backup. Each addition can increase the backup time noticeably.
8. Click **Start Backup**. System will display progress and then a backup complete message.
9. Click **OK**.
10. Verify the presence of the backup file on the local drive.

Restore the MCD-ISS Database

You need the following information and equipment to restore a database:

- Installer PC
- MSL system IP address
- MSL Server Manager username and password

Use the following procedure to restore a previously saved database.



Note: Only backup files from systems supporting the Global Data Model (GDM) can be restored.



Time: The system takes approximately 10 to 15 minutes to restore an average-sized database, during which time the files are copied to the server. Once the files have been copied, you must reset the server. Note that the system can take up to an additional 1 hour to reset.

Caution: You must restart the MCD application after restoring a database. Service will be LOST during this reboot.

1. Log in to the MSL Server Manager using a browser with the user name and password when initially configuring the MSL server.
2. Click **Mitel Communications Director**, located in the left-side panel under the **Applications** heading. The Mitel Communications Director main page displays.
3. Click **Restore MCD Backup File**. A new page displays asking for the path to the backup file.
4. Enter the full path to where the MCD backup file (or MSL backup file) is located.



Note: The backup file can be either an MCD or MSL backup file. The MSL backup file will be extracted to retrieve the MCD backup file. An error message displays if the MCD backup file is not included in the MSL backup.

5. Click **Upload**. The following information displays:
 - date and time of the backup file

- version of the backup data file
- two columns of configuration options:
 - the first column showing the current configuration options stored in the backup file
 - the second column is to set the proper configuration options for the restored database



Note: If an MSL backup file was restored which did not contain any License and Options (LOS) information for the MCD, N/A displays for those current configuration options. The new configuration options column will list the default values for those options.

6. Click **Restore** to begin restoring the database.
The page shows the progress status.



Tip: While the System Administration Tool is restoring the database, no other users can access any of the web-based tools. We recommend performing restores outside of business hours.

Disaster Recovery

Having a backup and recovery plan in place will contribute to mitigating any potential major outages. Such outages can include:

- Computer migration
- Hard disk replacement
- Hard disk re-formatting (e.g. clean installation of MSL)

To prepare for any potential disaster, implement a backup plan where a scheduled MSL backup will contain the MCD-ISS backup. MSL has a backup facility that will perform regular backups of the MSL databases and any completed MCD-ISS backups. MSL backups will include the most recent previously created MCD-ISS backup. As an added precaution, backup the MCD database separately using the MCD System Administration Tool. See “Back up the MCD-ISS Database” on page 35.

To recover from a disaster

1. Backup MSL and the MCD database. See “To schedule an MSL backup” on page 38.
2. Install the new MSL operating system software. See the *Mitel Standard Linux Installation and Administration Guide* for details.
3. Restore the MSL and the MCD database. See “Restore the MCD-ISS Database” on page 36.
4. Install the MCD-ISS software blade. See “Install the MCD for ISS Software” on page 13.
5. De-activate the ServiceLink account:
 - a. In the MSL Server Manager, click on **Status** located in the left-side panel under **ServiceLink**.
 - b. In the right-side panel, click the link in **If you wish to deactivate your ServiceLink account, please click [here](#)**.

- c. Click **Deactivate** on the next page that displays.
6. Log in to the AMC and clear the hardware ID.
7. Activate the ServiceLink account:
 - a. In the MSL Server Manager, click on **Status** located in the left-side panel under **ServiceLink**.
 - b. Complete the fields as appropriate and click **Activate**.
8. The recovery will automatically proceed until completion.

To schedule an MSL backup

1. Log in to the MSL Server Manager using a browser with the user name and password when initially configuring the MSL server.
2. Under Administration, click **Backup**.
3. From the Select an action list, click **Configure network backup**.
4. Click **Perform**.
5. Configure the server where the backup file will be stored:
 - a. Enter the **IP address** of the file server where the backup will be stored.
 - b. Enter the **Sharename** of the shared folder where the backup file will be stored. (For example, "Backups".) The shared folder must have permissions set to "Full Control".
 - c. Enter the **(Optional) Sub Directory** where the backup will be stored. If you leave this field blank, the file will be stored at the root of the shared folder. Spaces and multi-level directory names are permitted; for example, "MSL backup" and "MSL backup/2011/October" are valid sub directory names. Dashes (-) are not permitted.
 - d. Enter the **Username** to use when connecting to the backup server.
 - e. Enter the **Domain** or **Workgroup** name of the server. (For example, mitel.com.)
 - f. Enter the **Password** to use when connecting to the backup server. Available storage space is displayed.
 - g. Select the **Maximum number of backup files to keep** (1-999) on the server (default is 5). When the number of stored files reaches this maximum count, the oldest version is deleted.
6. Select the frequency with which you want to perform backups (Daily, Weekly, Monthly, Never). Backup file names will include timestamps in the format: mslserver_<hostname>_yyyy-mm-dd_hh-mm.tgz):
 - a. To disable regularly scheduled backups, click **Disabled**.
 - b. For **Daily** backups, select a time of day (hour, minute, AM/PM)
 - c. For **Weekly** backups, select a time of day, and day of the week
 - d. For **Monthly** backups, select a time of day, and day of the month
 - e. For **immediate** backup file creation, proceed to the next step.
7. To test your backup configuration, or to run an immediate backup, click **Backup Now**.

8. Click **Save** to save the schedule information.

If the scheduled backup fails, an alarm is raised and can be seen in the Event Viewer panel. Refer to the *Mitel Standard Linux Installation and Administration Guide* for details.

For MCD-ISS releases prior to Release 6.0, separately restore the MSL backup and the MCD-ISS backup. Refer to the *Mitel Standard Linux Installation and Administration Guide* for details about restoring the MSL backup; follow the procedures in “Upgrade the MCD for ISS software using a fresh installation” on page 33, beginning at Step 3.

MCD for ISS on Red Hat Enterprise Linux

Upgrade the MCD for ISS Software

The MCD software upgrade process consists of backing up and restoring the databases, and removing the current software. Database information such as the System (Call Server) IP and ARID is retained in the restored databases during the upgrade process.

Caution: This upgrade process will cause a service interruption.

To upgrade the MCD for ISS software blade on RHEL:

1. Back up the MCD Call Server database using the MCD System Administration Tool (see “Back up the Call Server Database” on page 39).
2. Place the MCD-ISS software media into the CD/DVD ROM drive of the Status ftServer.
3. To mount the MCD-ISS image, enter:
mount /dev/cdrom /media
4. To run the installation script, enter:
/media/Software/RHEL/install.sh
5. To upgrade the MCD software, enter:
mcd_setup upgrade
6. Restore the Call Server Database (see “Restore the Call Server Database” on page 40).

Back up the Call Server Database



Tip: It is very important to maintain current database backups; backups should be done on a regular basis.

You need the following information and equipment to back up a database:

- Installer PC
- System IP address for the MCD for ISS blade

- System Administration Tool username and password

Use the following procedure to back up a database.



Time: The system takes approximately 10 to 15 minutes to back up an average-sized database (50 - 100 MB).

Caution: During a system backup, no other users can access any of the web-based tools (Desktop Tool, Group Administration Tool, or System Administration Tool), or save changes. To avoid blocking other users, we recommended that you perform system backups outside of business hours.

1. Access the MCD System Administration Tool. See “Launch the MCD System Administration Tool” on page 14.
2. Click **Maintenance and Diagnostics** from the drop-down menu in the **Selection** area on the left.
3. Click **Backup**.
4. Copy the **identitydb.obj** file to your PC (required for every user profile on every PC used for backup and restore). Follow the instructions displayed on the screen.



Tip: Do this only once per PC per user.

5. Click **Browse** to launch the **Save As** dialog box, then navigate to the location on your local drive where you want to save the backup file (for example C:\3300_ICP\backup).
6. Type a name for your backup file, and then click **Save As**.
7. Select the check box for Call History records if you want them included in your backup. Each addition can increase the backup time noticeably.
8. Click **Start Backup**. System will display progress and then a backup complete message.
9. Click **OK**.
10. Verify the presence of the backup file on the local drive.

Restore the Call Server Database

You need the following information and equipment to restore a database:

- Installer PC
- System IP address for the MCD for ISS blade
- System Administration Tool username and password

Use the following procedure to restore a previously saved database.



Time: The system takes approximately 10 to 15 minutes to restore an average-sized database, during which time the files are copied to the server. Once the files have been copied, you must reset the server. Note that the system can take up to an additional 1 hour to reset.

Caution: You must restart the server after restoring a database. Service will be LOST during this reboot.

1. Access the MCD System Administration Tool. See “Launch the MCD System Administration Tool” on page 14.
2. Click **Maintenance and Diagnostics** from the drop-down menu in the **Selection** area on the left.
3. Click **Restore**.
4. Copy the **identitydb.obj** file to your PC (required for every user profile on every PC used for backup and restore). Follow the instructions displayed on the screen.



Tip: If you are doing the restore on the same PC the backup was saved to and you are logged in as the same user (same user profile), you do not need to copy the **identitydb.obj** again.

5. Type the location of the database that is being restored, or use the browse facility.
6. Click **Yes** if you want to include Hotel/Motel wake-up information in your restore.
7. Choose the Dimension Selections:
 - if there are no changes to the software dimensions, accept **Use Dimension Selections from backup file**
 - OR
 - click **Use Current Dimension Selections** if you are restoring the database after programming new Dimension Selection information.
8. Click **Start Restore**.
9. Click **OK**. The system shows an "in progress" message.
10. When the status window shows "complete", click **OK**.
11. **Reset** the system:
 - a. Log into the MCD System Administration Tool. See “Launch the MCD System Administration Tool” on page 14.
 - b. In the Maintenance Commands form enter the **reset system** command.
 - When the reset is complete, the database is converted, and the system **automatically resets**.
 - If you have programmed Dimension Selection, the system reboots automatically one more time.



Tip: While the System Administration Tool is restoring the database, no other users can access any of the web-based tools. We recommend performing restores outside of business hours.

Routine Maintenance Procedures

A number of commands enable you to perform basic maintenance on the MCD for ISS on RHEL platform. For details, see:

- “Reset the Application Record ID (ARID)” on page 42
- “Collect MCD for ISS Logs” on page 42
- “Monitor the System Status” on page 42

Reset the Application Record ID (ARID)

Use this procedure to clear the existing ARID, enter a new one, and then re-synchronize with the AMC.

To reset the ARID:

1. Open a command prompt.
2. To clear the current ARID, enter:
mcd_setup arid clear
3. To enter a new ARID (after clearing the current ARID), enter:
mcd_setup arid <nnnnn>
4. To synchronize with the AMC, enter:
mcd_setup arid sync

Collect MCD for ISS Logs

Use this procedure to collect MCD-level logs on the RHEL server platform.

To collect and save log files:

1. Open a command prompt.
2. To generate the tarball file, enter:
mcd_logs_collect
The tarball file is stored under /tmp/mcd-logs.tgz.
3. Copy the tarball file and send it to Mitel Product Support for analysis.

Monitor the System Status

Use this procedure to do the following:

- monitor the system upgrade or licensing status

- verify that the MCD is licensed
- display the current logging operation (license/upgrade) to the screen using the -v modifier

To determine the system status:

1. Open a command prompt.
2. To monitor the upgrade and licensing status, enter:

mcd_status

3. To verify that the MCD is licensed, enter:

mcd_status

4. To display the current logging operation, enter:

mcd_status -v

Troubleshooting

Installation and Upgrade

Table 1: Installation and Upgrade Troubleshooting

Symptom	Possible Cause	Corrective Action
MCD for ISS licensing failed on Mitel Standard Linux platform. Note: This tip does not apply to the MCD-ISS/RHEL platform.	Incorrect ARID provisioned for the server.	Clear the hardware ID associated with the ARID on the AMC.
		De-activate and re-activate your ServiceLink account in the Status section of the Server Manager.



GLOBAL HEADQUARTERS	U.S.	EMEA	CALA	ASIA PACIFIC
Tel: +1(613) 592-2122 Fax: +1(613) 592-4784	Tel: +1(480) 961-9000 Fax: +1(480) 961-1370	Tel: +44(0)1291-430000 Fax: +44(0)1291-430400	Tel: +1(613) 592-2122 Fax: +1(613) 592-7825	Tel: +61(0) 2 9023 9500 Fax: +61(0) 2 9023 9501

FOR MORE INFORMATION ON OUR WORLDWIDE OFFICE LOCATIONS, VISIT OUR WEBSITE AT MITEL.COM/OFFICES

THIS DOCUMENT IS PROVIDED TO YOU FOR INFORMATIONAL PURPOSES ONLY. The information furnished in this document, believed by Mitel to be accurate as of the date of its publication, is subject to change without notice. Mitel assumes no responsibility for any errors or omissions in this document and shall have no obligation to you as a result of having made this document available to you or based upon the information it contains.

M MITEL (design) is a registered trademark of Mitel Networks Corporation. All other products and services are the registered trademarks of their respective holders.

© Copyright 2013, Mitel Networks Corporation. All Rights Reserved.

mitel.com

